



TR-808 Software Rhythm Composer

Owner's Manual

Introduction

For details on the settings for the DAW software that you're using, refer to the DAW's help or manuals.

About Trademarks

- VST is a trademark and software of Steinberg Media Technologies GmbH.
- Roland is a registered trademark or trademark of Roland Corporation in the United States and/or other countries.
- Company names and product names appearing in this document are registered trademarks or trademarks of their respective owners.



Screen Structure

Main window

This area shows various knobs and sliders that you can use to edit the sound.

[LIST] button

Displays the Memory Select window.

Level meter

Shows the output level.

[▲] [▼] buttons

Recall the previous or next pattern or kit.

Display (upper line)

Shows the bank name.

Display (center line / lower line)

Shows the selected pattern name and kit name.

[WRITE] button

Saves the pattern or kit.

[VOLUME] knob

Adjusts the volume.

[INSTRUMENT SELECT] knob

Selects the instrument that is indicated by the instrument pads.

[SHUFFLE] knob

Adjusts the amount of shuffle (swing).

* This is multiplied with each instrument's shuffle setting in Pattern Edit. If the instrument's shuffle setting is 0, shuffle is not applied even if you turn this knob.

[OPTION] button

Lets you make various settings, or authorize the software.

[HELP] button

Displays help.

[ABOUT] button

Displays information about TR-808 Software Rhythm Composer.

[PANEL] button

Switches the instrument edit section's display to GAIN, PAN, and TUNE (Bass Drum only).



Instrument edit section

Here you can edit the tonal character of the instruments. You can use 11 different instruments (BD–CH) in a pattern.

[LEVEL] knob

Adjusts the volume of the instrument.

[TUNING] knob

Adjusts the pitch of the tom or conga.

[SNAPPY] knob

Corresponds to the resonating wires of a snare drum.

Turning the knob toward the left produces the sound of when the resonating wires are removed.

[TONE] knob

Adjusts the tension of the head for the bass drum or snare drum; adjusts the tonal character for the cymbal.

[DECAY] knob

Adjusts the decay of the sound. Turning the knob toward the left makes the sound crisper, and turning it toward the right extends the decay.

Instrument select switch

This switch selects one of two instruments. The two instruments cannot be played simultaneously.

Use the [PANEL] button to switch

[GAIN] knob

Adjusts the gain of each instrument.

[PAN] knob

Adjusts the pan (left/right position) of each instrument.

[TUNE] knob

Adjusts the pitch of each instrument.



[A]–[H] buttons

Switch the variation (A–H) that plays. To make a multiple selection, hold down the [Shift] key. The currently playing variation button blinks.

[START/STOP] button

Plays or stops the pattern.

[EDIT] button

Displays the pattern edit area.


Instrument pads

Sound is produced when you click these.

While a pattern plays, these pads light to indicate the playback steps of the instrument selected by the [INSTRUMENT SELECT] knob.


Sound Engine Structure

TR-808 Software Rhythm Composer




What Is a "PATTERN"?

The performance data that you record is called a "pattern."
 The TR-808 Software Rhythm Composer has 128 patterns (16 patterns x 8 banks); each pattern has eight variations (A-H).




What Is a "KIT"?

The 11 instruments are collectively called a "kit."
 The TR-808 Software Rhythm Composer has 128 kits.
 The pattern plays the instruments of the currently selected kit.



A pattern plays the inst of the kit.



Edit Window



Parameter	Value/Explanation
EDIT VARIATION SELECT buttons	A-H: Select the variation that you want to edit. CURRENT: Select the currently playing variation.
[SCALE] button	Selects the scale. The scale changes each time you press the button. The vertical stripes that are the background of the step buttons are spaced at quarter-note intervals.
[LAST STEP] button	Specifies the length of the pattern. You can set this individually for each instrument.
[WEAK] button	Turn this on to enter weak beats.
[FLAM] button	Turn this on to enter a flam.
FIAM TYPE	Specifies the spacing of the flam. Click the text "TYPE" TYPE1: 0msec TYPE2-9: Specify a spacing of 20-48 msec in 4 msec units.
[SUB STEP] button	Turn this on to enter sub steps.
SUB STEP TYPE	Specifies the type of sub step. Click the text "TYPE" TYPE1: Duplets TYPE2: Triplets TYPE3: Quadruplets
TOTAL ACCENT	Illuminate the steps that you want to accent. The strength of the accent is specified by the ACCENT [LEVEL] knob in the main window. (Accents apply to the same step of all instruments.)
Instrument selection	Select the instruments for which the variation/step is shown in the main window or edit window.

Parameter	Value/Explanation
Variation indicator	This indicates the variation A-H that is playing for each instrument. Even if different instruments have a different LAST STEP setting, and the variations being played do not match, this shows the currently playing variation for each instrument.
[M] (mute) / [S] (solo) button	Specify mute/solo settings for each instrument (solo has priority).
[SHUFFLE] slider	Specifies the amount of shuffle (rhythmic bounce) for each instrument. If the shuffle setting in the main window is set to "0," this has no effect.
Step sequencer area	This is a step sequencer that shows all instruments as a list.

Specifying the Pattern Length (LAST STEP)

1. Click the [LAST STEP] button

The [LAST STEP] button blinks purple.

The default is 16 steps.

2. For each instrument, press the button that you want to specify as the last step; the button blinks.

Inputting Steps

1. For each instrument, input steps by making the step buttons lit or unlit.

Lit steps produce sound; unlit steps are silent.

Inputting the Total Accent (TOTAL ACCENT)

The top row of step buttons are for inputting the total accent.

1. Make the button light for each step at which you want to apply an accent.

An accented note is heard for all instruments that sound at a step whose total accent button is lit.

Inputting Weak Beats

1. Click the [WEAK] button.

The [WEAK] button is lit white, allowing you to input weak beats.

2. Turn on the steps that you want to play as weak beats.

The steps for which you input a weak beat are lit dimly.

MEMO

Even without making the [WEAK] button lit, you can input a weak beat by clicking a step while holding down the [SHIFT] key.

Specifying a Flam

1. Click the [FLAM] button.

The [FLAM] button is lit yellow, allowing you to enter flams.

Click "FLAM TYPE" to select the flam spacing.

2. Turn on the steps at which you want to play a flam.

You can enter flams in combination with weak beats.

Inputting Sub Steps

1. Click the [SUB STEP] button.

The [SUB STEP] button is lit, allowing you to enter sub steps.

Click "SUB STEP TYPE" to select the sub step type.

Depending on the sub step type, this is lit light blue (duplets), green (triplets), or dark blue (quadruplets).

2. Turn on the steps at which you want to play a sub step.

You can enter sub steps in combination with weak beats.

Editing a Variation

Right-click the EDIT VARIATION SELECT button to use the following functions.



Function	Explanation
COPY	Copies the patterns of all instruments in the selected variation.
PASTE	Pastes the copied variation to the selected variation. The variation is overwritten.
CLEAR	Erases the selected variation.

Editing an Instrument

Right-click an instrument name at the left side of the edit area to use the following functions.



Function	Explanation
COPY	Copies the pattern of the selected instrument.
PASTE	Pastes the copied pattern to the selected instrument. The instrument is overwritten.
CLEAR	Erases the pattern of the selected instrument.
INVERT	Exchanges the steps that sound the selected instrument with the steps that are silent.
ALL	Turns on all steps of the selected instrument so that they all sound.


Placing a Pattern in a DAW Track

Performance data from the variation [A]–[H] buttons can be placed in a track of your DAW, either as MIDI or audio data.

Use the [OPTION] button to choose whether you're placing MIDI data or audio data.



Drag and drop



DAW Multi-Out Support

If you're using this plug-in with a host application that supports multiple output, you can use a different output for each instrument.

The output assignment for each instrument is as follows.

Output	Instrument
Main out	Mix
Sub out 1	Bass Drum
Sub out 2	Snare Drum
Sub out 3	Low Tom / Low Conga
Sub out 4	Mid Tom / Mid Conga
Sub out 5	High Tom / High Conga
Sub out 6	Rim Shot / Claves
Sub out 7	Hand Clap / Maracas
Sub out 8	Closed Hihat
Sub out 9	Open Hihat
Sub out 10	Cymbal
Sub out 11	Cowbell

* For more about multi-output settings in your host application, refer to the help or owner's manual of your host application.

How Note Numbers Select Sounds or Variations

Note numbers received by TR-808 Software Rhythm Composer select the following sounds or variations.

Note number	Sound/Function
24-31	Variation Select A-H
35, 36	Bass Drum
37	Rim shot/Claves
38, 40	Snare Drum
39	HandClap/Maracas
42, 44	Closed HiHat
41, 43	LoTom/LoConga
46	Open HiHat
45, 47	MidTom/MidConga
49	Cymbal
48, 50	HiTom/HiConga
51	Cowbell

About CC (Control Change)

TR-808 Software Rhythm Composer receives the following CC messages.

CC#	Parameter
9	SHUFFLE
20	BD TUNE
21	BD TONE
22	BD COMP
23	BD DECAY
24	BD LEVEL
25	SD TONE
26	SD SNAPPY
27	SD COMP
28	SD DECAY
29	SD LEVEL
46	LT TUNE
47	LT DECAY
48	LT LEVEL
49	MT TUNE
50	MT DECAY
51	MT LEVEL
52	HT TUNE
53	HT DECAY
54	HT LEVEL
55	RS TUNE
56	RS DECAY
57	RS LEVEL
58	CP TUNE

CC#	Parameter
59	CP DECAY
60	CP LEVEL
61	CH TUNE
62	CH DECAY
63	CH LEVEL
71	TOTAL ACCENT
80	OH TUNE
81	OH DECAY
82	OH LEVEL
83	CY TONE
84	CY DECAY
85	CY LEVEL
86	CB TUNE
87	CB DECAY
88	CB LEVEL

Patterns/Kits and Banks

1. Click the [LIST] button.

The Memory Select window opens.

The screenshot shows a window titled 'Initial 1' with a 'PATTERN' and 'KIT' section. The 'PATTERN' section lists items like 'A-1: Sample 1', 'A-2: Sample 2', etc., up to 'D-8'. The 'KIT' section lists 'M-1' through 'P-8'. A toolbar on the left contains buttons for [NEW], [DELETE], [LOAD], and [SAVE]. A toolbar at the bottom contains buttons for [WRITE], [RENAME], and [READ]. A callout box points to the [NEW] button, another to [DELETE], another to [LOAD], and another to [SAVE]. A callout box points to the [WRITE] button, another to [RENAME], and another to [READ]. A callout box points to the 'i' symbol in the bottom left corner. A callout box points to the 'PATTERN' and 'KIT' headers, indicating they switch between patterns and kits. A callout box points to the selected memory item 'A-1: Sample 1', indicating it is highlighted.

[NEW] button
Creates a new empty bank.

[DELETE] button
Deletes the selected bank.

[LOAD] button
Loads a bank from a file.

[SAVE] button
Exports a bank as a file.

[WRITE] button
Saves the edited pattern/kit as a memory in the bank.

[RENAME] button
Renames the selected memory.

[READ] button
Loads a memory from a bank.

"i" symbol
When you place the mouse cursor (mouse pointer) over this, a list of shortcuts appears.

Switches between patterns and kits.

The selected memory is highlighted.

Bank

A "bank" contains 128 patterns and 128 kits. By switching banks, you can access a large number of patterns or kits. A bank can be saved as a file.

Bank	
Pattern	Kit
1	1
2	2
3	3
⋮	⋮
128	128

Changing to Other Bank

1. Click the Bank field.

The bank list window opens.

2. Click the bank that you want to recall.

By pressing the [▲] [▼] buttons located at the right of the bank field, you can switch to the next or previous bank.

Exporting the Bank

Here's how to export a bank as a file.

1. Click the [SAVE] button.

The file name input window opens.

2. Enter a file name and save.

The file is exported.

Importing a Bank

1. Click the [LOAD] button.

The file selection window opens.

2. Select a file and load it.

The bank is loaded.

Creating/Deleting a Bank

Creating a bank

Click the [NEW] button to create a new empty bank.

Deleting a bank

Here's how to delete the selected bank.

- 1. Select a bank as described in "Changing to Other Bank" (p. 9).**
- 2. Click the [DELETE] button.**
A confirmation message appears.
- 3. Click [OK] to delete the bank.**

Renaming a Bank

- 1. Select a bank as described in "Changing to Other Bank" (p. 9).**
- 2. At the left of the bank field, click ►.**
- 3. Edit the name and press the [Return (Enter)] key.**

Patterns and Kits

TR-808 Software Rhythm Composer manages 128 patterns and kits as one bank.

Loading a Pattern or Kit

Here's how to load a pattern or kit that's saved in a bank. When you load a pattern or kit, its settings are shown in the edit area, allowing you to edit the settings.

- 1. Click the number of the memory that you want to load.**
- 2. Click the [READ] button. Or press the [Return (Enter)] key.**

The pattern or kit is loaded.

* You can also load a pattern or kit by double-clicking the pattern or kit number.

Saving a Pattern or Kit

Here's how to save your edited sounds in the bank as a pattern or kit.

- 1. Click the number of the memory in which you want to save the sound.**
- 2. Click the [WRITE] button.**

The pattern or kit are saved in the bank.

Renaming a Pattern or Kit

- 1. Click the number of the memory that you want to rename.**
- 2. Click the [RENAME] button.**
- 3. Change the memory name. (Up to 16 letters)**

MIDI Learn Function

Here's how to associate a MIDI control change with a sound parameter, so that the parameter can be controlled by that MIDI message.

Procedure



1. Right-click the sound parameter controller (knob or slider).
2. Choose "Learn MIDI CC."
3. Operate your external MIDI device to transmit a control change message.

NOTE

You can't associate more than one MIDI control change with a single controller. Only the most recent setting is used.

Cancelling



1. Right-click the sound parameter controller (knob or slider).
2. Choose "Forget MIDI CC."

Setting

Option

1. Click the [OPTION] button.

2. Select items.

A ✓ is shown for the selected item.

Item	Explanation
Layout	Original: This is the conventional screen layout. Compact: This condenses the space for other than knobs and buttons, using less screen area.
Zoom	Changes the size of the main window.
Position Lock to DAW	Specifies whether TR-808 Software Rhythm Composer synchronizes with your DAW's start/stop operations and playback position. Turn synchronization off if you're using the tracks of your DAW to play the rhythm.
Drag & Drop Pattern as MIDI	When you place variation performance data in your DAW, it is placed as MIDI data.
Drag & Drop Pattern as Audio	When you place variation performance data in your DAW, it is placed as audio data.
Optimize for Lower CPU Usage	Turn this ON if CPU usage is high, and clicks or pops occur.
Flip Scroll Direction	Inverts the direction of rotation when using the mouse wheel to edit a value (Only on Mac). The direction is inverted if Flip Scroll Direction is set to ON.
Roland Cloud...	Displays the Roland Cloud site.
Authentication...	Performs user authentication for the TR-808 Software Rhythm Composer.